



Ingmar Bergman 100

① Contents in box:



② Contents, how to connect:



Ingmar Bergman 100

③ How to use:

When power is connected please wait about 60 seconds for the media player to start. After startup, choose your preferred language (picture 1), this is only done once, if you want to change the language you have to disconnect the power and restart the media player.

After language has been chosen the start screen will be picture 2, here you click on the number of the film you want to watch.



Picture 1
Start up screen, choose preferred language



Picture 2
Choose the film you want to watch by clicking on the number or title.

④ How to pack:



Power adaptor, power cable and HDMI-cable

All other equipment



Media player on top